

1. Open Trunk
2. Pull back carpet on left side of the trunk by wheel well and locate fuel level module



3. Unplug fuel level module





4. Plug in DSC Sport module



4. Put carpet back in place